

TOPSIDE (WITH EXTENSION) INSTALLATION GUIDE

When you are ready to install your topside control, if you don't already have a knock-out that's at least 1.75" in diameter, you can use a 1.75" (1 3/4") hole saw bit to make the hole needed. Simply drill the hole in the center of where you'll be installing the topside.

Once ready, snake the cable from the control up through the topside cutout and plug it into the topside.

Make sure the surface you will be mounting to is clean and dry before proceeding!

If you are replacing an existing topside (or a number of air buttons) and the knock-out is bigger than your new United Spas topside, simply affix the topside to the included extension plate by peeling off the paper over the adhesive on the back of the topside and placing the topside centered through the hole of the plate, slowly pressing firmly around the perimeter once centered and placed to insure a firm seal before proceeding to the next step.

Now, simply center the topside (or extension plate with topside attached) over the existing cutout, remove the paper over the adhesive on the back of the topside/extension plate and press into place, slowly pressing all around the perimeter of the plate firmly for a few seconds each area, to assure a firm bond.

Allow 2-4 hours for adhesive to thoroughly bond before use.